


Hand Crimp Tool



Insulated Terminals

26 to 22 AWG (0.5mm²)

24 to 18 AWG (0.75mm²)

22 to 16 AWG (1.25mm²)

Crimping Instruction

- Put the terminal and wire on the hand tool. (Must according to the terminal size change die size)
- Hold the handle, begin to press the terminal, to press till loose to the tenon.
- Turns on the handle, then takes out is pressing the post.

Part Number Table

Description	Part Number
Hand Crimping Tool	MC001270

Important Notice : This data sheet and its contents (the "Information") belong to the members of the Premier Farnell group of companies (the "Group") or are licensed to it. No licence is granted for the use of it other than for information purposes in connection with the products to which it relates. No licence of any intellectual property rights is granted. The Information is subject to change without notice and replaces all data sheets previously supplied. The Information supplied is believed to be accurate but the Group assumes no responsibility for its accuracy or completeness, any error in or omission from it or for any use made of it. Users of this data sheet should check for themselves the Information and the suitability of the products for their purpose and not make any assumptions based on information included or omitted. Liability for loss or damage resulting from any reliance on the Information or use of it (including liability resulting from negligence or where the Group was aware of the possibility of such loss or damage arising) is excluded. This will not operate to limit or restrict the Group's liability for death or personal injury resulting from its negligence. Multicomp is the registered trademark of the Group. © Premier Farnell plc 2012.

www.element14.com
www.farnell.com
www.newark.com

