

Vacuum Base Repair Kit

Repair your torn or damaged vacuum base pad!

For use with PanaVise 380 and 381 vacuum bases.

- To determine if your Vacuum Base needs replacing, clean the pad with a clean towel and make sure that is free of debris. Then attach it to a clean, non-porous surface (such as a window). If it still loses suction, the pad needs to be replaced.
- Includes rubber pad, handle and lock washer
- For 380 Vacuum Base or 381 Vacuum Base PanaVise



In Use Example for the Vacuum Base Repair Kit



Before you consider a Vacuum Base Repair Kit, clean the pad and then test on a known flat, smooth and non-porous surface like a piece of glass or window.



Before you consider a Vacuum Base Repair Kit, clean the bottom of you current pad with water or a simple glass cleaner and then check to see if it holds.
